




Autofocus Fiber
Laser Cutting Head
NC62



User Manual
Shenzhen Worthing Technology Co., Ltd.




Attention


Please read this manual carefully and make sure you understand its contents before using the laser head.


Please keep this manual for future operation and maintenance.



Contents

1. Product Structure-----	1
1.1 Dimension-----	2-3
1.2 Debugging-----	4
1.3 Port Definitions-----	5-11
1.4 Fiber Connection-----	12-13
1.5 Optical Center Adjustment-----	14
1.6 Platform Configuration-----	15
2. Maintenance	
2.1 Regular Maintenance-----	16
2.2 Ceraminc/Nozzle-----	17
2.3 Protective Window1-----	18
2.4 Protective Window2-----	19
2.5 Protective Window3-----	20
2.6 Collimating Lens-----	21
2.7 Focusing Lens-----	22
3. Lens detection and monitoring	
3.1 Monitoring interface -----	23
3.2 Monitoring parameter -----	24












Step 1: set the laser power to 500W, make a short burst at the height of 5cm from the plate, burn a round scorch on the plate;





Step 2: set the laser power to 100W, make a short burst at the height of 1~5 cm from the plate, burn a round scorched spot on the plate;




Step 3: compare the concentricity;







1	W
2	U
3	V
4	FG(Ground)

Servo Motor Power Supply Interface (Red)



Pin	Definition
shell	Shielded wire
1	-D (Encoder Signal Data-)
2	+D (Encoder Signal Data+)
3	SG (Signal Ground)
4	VCC (Encoder Power +5V)
5	+24V(Approach Switch Power)
6	0V (Approach Switch Power)
7	W+ (Approach Switch Power)
8	W- (Approach Switch Power)

Servo Motor Encoder & Approach Switch Interface (Green)



Pin	Definition
1	24V Ground
2	24+ Power
3	232 Ground
4	Alarm reset
5	ALM - OUT
6	232 TX
7	232 RS
8	Null
9	Null

Lens Monitoring Signal Interface (Red)

Sankyo Servo Drive and Motor Connection

单轴驱动器 50W~400W TYPE-M, TYPE-M2

主回路电源

电路断路器
浪涌吸收器

干扰滤波器

高压电连接

非危险电压连接
D类接地为100Ω以下

图例

高压电连接

非危险电压连接

D类接地为100Ω以下

控制电源 DC24V

控制电源 DC24V

S-TUNE

上位控制装置

控制信号

I/O电缆

编码器电缆

电机动力电源

再生电阻

连接动态制动器回路

电机制动器控制回路


连接制动器控制回路

6

Friendess FSCUT2000A laser cutting control system BCL3764 terminal plate W axis DB15 servo control interface connect with Sankyo servo driver 50P interface definition

Friendess DB15 servo control interface		Sankyo 50P interface	
Signal	Pin	Pin	Signal
PUL+	1	26	CMD PLS
PUL-	9	27	/CMD PLS
DIR+	2	30	CMD DIR
DIR-	10	31	/CMD DIR
A+	3	36	OUT A
A-	11	37	OUT /A
B+	4	38	OUT B
B-	12	39	OUT /B
Z+	5	40	OUT Z
Z-	13	41	OUT /Z
24V	8	3	COM1
SON	6	1, 3	24V, COM1
CLK	7	4	SVON
ALM	14	5	RESRT
OV	15	21	ALM+
		2, 12, 22	0V, COM2, ALM-

Definition of laser focusing adjustment range limitation switch connector



Parts of parameter list, subject to actual using and Sankyo servo instruction.

Parameter	Value	Parameter	Value	Parameter	Value
NO. 2	0	NO. 49	2500	NO. 55	5000
NO. 3	1	NO. 50	3000	NO. 102	750
NO. 32	0	NO. 51	5000	NO. 103	100
NO. 34	32768	NO. 52	3000	NO. 276	2500
NO. 36	2500	NO. 53	5000	NO. 278	32768
NO. 48	32768	NO. 54	3000	NO. 32.1	1


Baidu Cloud Disk : <https://pan.baidu.com/s/1c07iME>

Note: 1.Definitions of servo driver and servo motor connector shown in Sankyo servo driver instruction; 2.Please use uniphase power, L connects to L1; N connects to L2.

Friendess FSCUT4000A laser cutting control system BCL3724 terminal plate W axis DB15 servo control interface connect with Sankyo servo driver 36P interface definition

Friendess DB15 servo control interface		Sankyo 50P interface	
Signal	Pin	Pin	Signal
DA	1	32	A-SPEED
AGND	9	33	A-GND
A+	3	36	OUT A
A-	11	37	OUT /A
B+	4	38	OUT B
B-	12	39	OUT /B
Z+	5	40	OUT Z
Z-	13	41	OUT /Z
24V	8	1, 3	24V, COM1
OS	2	--	--
SON	6	4	SVON
CLK	7	5	RESRT
OV	10	2	G24
ALM	14	21	ALM+
OV	15	12, 22	COM2, ALM-

Definition of laser focusing adjustment range limitation switch connector



Parts of parameter list, subject to actual using and Fuji servo instruction.

Parameter	Value	Parameter	Value	Parameter	Value
NO. 2	1	NO. 49	2500	NO. 55	5000
NO. 3	2	NO. 50	3000	NO. 102	750
NO. 32	0	NO. 51	5000	NO. 103	100
NO. 34	32768	NO. 52	3000	NO. 276	2500
NO. 36	2500	NO. 53	5000	NO. 278	32768
NO. 48	32768	NO. 54	3000	NO. 32.1	1

Baidu Cloud Disk : <https://pan.baidu.com/s/1c07iME>


Note: 1.Definitions of servo driver and servo motor connector shown in Sankyo servo driver instruction; 2.Please use uniphase power, L connects to L1; N connects to L2.

伺服驱动器与电机连接

安川7系系统构成示例

Σ -7S伺服单元+旋转型伺服电机

单相AC200V




注意:

小功率产品不需要使用三相供电，如需要使用，请务必在前级加装电压稳压器。


Friendess FSCUT2000A laser cutting control system BCL3764 terminal plate W axis DB15 servo control interface connect with YASKAWA servo driver 50P interface definition

Friendess DB15 servo control interface

YASKAWA Σ-V servo 50P interface



Definition of laser focusing adjustment range limitation switch connector



Parts of parameter list, subject to actual using and YASKAWA servo instruction.


parameter	value	parameter	value	parameter	value
PN000	0011	PN109	0~100	PN210	2500
PN00B	0101	PN10A	0~6400	PN212	2500
PN100	120	PN170	1400	PN50A	8100
PN101	10	PN200	0000	PN50B	6548
PN102	180	PN20E	4194304	PN401	0.53
PN103	100				

Note: 1.Definitions of servo driver and servo motor connector shown in YASKAWA servo driver instruction; 2.Please use uniphase power, L connects to L1&L1C; N connects to L2&L2C.


Friendess FSCUT4000A laser cutting control system BCL3724 terminal plate W axis DB15 servo control interface connect with YASKAWA servo driver 50P interface definition

BCS100 servo driver interface

YASKAWA Σ series servo 50P interface



Definition of laser focusing adjustment range limitation switch connector




Definition of laser focusing adjustment range limitation switch connector


parameter	value	parameter	value	parameter	value
PN000	0001	PN109	0~100	PN210	2500
PN00B	0101	PN10A	0~6400	PN212	2500
PN100	120	PN170	1400	PN50A	8100
PN101	10	PN200	0000	PN50B	6548
PN102	180	PN20E	4194304	PN401	0.53
PN103	100				

Note: 1.Definitions of servo driver and servo motor connector shown in YASKAWA servo driver instruction; 2.Please use uniphase power, L connects to L1&L1C; connects to L2&L2C.


1. Place the laser head and optical fiber connector in a horizontal state;
2. Clean the QBH and fiber connector with clean rod and ethyl alcohol.




3. Insert the fiber connector into QBH gently;



4. After inserting, turn the turning rim in the arrow direction until the two red marks are aligned to the white mark;




5. Then pull the turning rim as the picture below;



6. Turn the rim in the direction as picture below at moderate intensity to make it tight (Use thumb and index finger).


The red marks can be aligned to or over the middle of the white bar, but do not twist any more when it is in the right position.





Note: Do not twist vigorously , it may cause damage to precision machinery.



To avoid dust or dirt entering into the fiber optic connector by accident, please clean the fiber rod first. Insert the fiber plug with the laser head in a horizontal position.



1. Adjust the X/Y screw by allen wrench and make the beam pass through the center of nozzle;
2. The cutting effect is best when the beam pass through the center of nozzle;
3. If the beam does not pass through the center of nozzle, it may cause the beam could not be emitted out or bad cutting effect and so on.



Methods of testing whether the beam pass through the center of nozzle:

1. Paste the transparent tape on the outlet of the nozzle (prefer to a new or undeformed nozzle);
2. Set the power of laser machine to 50W(take 500W for example, adjust the short burst power for 10%);
3. Take off the transparent tape after the beam has been emited for 1 - 2 seconds;
4. Face the tape to light source and observe the round mark of nozzle on the tape and burned spot of laser passing through the tape.
5. If they are concentric, the testing result is good, but if not, please keep adjusting.
6. When adjustment is finished, tighten the center locking ring (red part) immediately.



Machine Config Tool(BMC1604)

Machine

Focus Control

Enable

The fourth axis Precitec HighYAG BCL4516E[No Connection]

Focus Range: From -16mm to 16mm

Focus position at org: 0mm

Pulse Rate: Move 7.22mm need 10000 pulse

High Speed: 5mm/s Org Dir Pos Neg

Low Speed: 1mm/s ORG signal: [Limit]

Rollback distance: 16.5mm subject to actual physical focus

Jog speed: 5mm/s

Locate Speed: 50mm/s

acceleration: 3000mm/s²

Servo Alarm Logic: NC

Negative Limit Logic: NC

Positive Limit Logic: NC

IO

Alarms

Inputs

Outputs

Wireless pendant

Wireless pendant

File Location

File Location

Note: 1. This parameter is default value; when user changes it, please avoid hard ware damage;
 2. Please contact technician to get specific parameters of different lens combinations.

Return Org

Soft limit Prompt go Org at start Prompt go Org in warning

X ORG direction: Neg Pos Y ORG direction: Neg Pos

ORG signal: Org Limit Limit logic: Set in detail




Z-Phase signal: Enable


High Speed: 50mm/s X rollback dis 10mm

Low Speed: 10mm/s Y rollback dis 10mm

Name	Logic
X +limit	<input checked="" type="radio"/> NO <input type="radio"/> NC
X -limit	<input checked="" type="radio"/> NO <input type="radio"/> NC
X origin	<input checked="" type="radio"/> NO <input type="radio"/> NC
Y +limit	<input checked="" type="radio"/> NO <input type="radio"/> NC
Y -limit	<input checked="" type="radio"/> NO <input type="radio"/> NC
Y origin	<input checked="" type="radio"/> NO <input type="radio"/> NC
W +limit	<input type="radio"/> NO <input checked="" type="radio"/> NC
W -limit	<input type="radio"/> NO <input checked="" type="radio"/> NC
W origin	<input type="radio"/> NO <input checked="" type="radio"/> NC

Note: 1. Please choose normally closed mode for normally closed limitation switch.






POWER




COOLING GAS



CUTTING GAS




center checking



Loosen the screws and remove



Pay attention to dust: when removing and installing the lens, wear dust gloves and finger covers in a clean place . When changing lens, use adhesive paper to paste sealed window, prevent dust to enter the interior cause pollution



1、Pressing ring 2、Protective glass


Note : Remove in the direction of the arrow, otherwise it may cause damages.
DO NOT operate with wrench or iron plier.





Loosen the screws and remove

Pay attention to dust: when removing and installing the lens, wear dust gloves and finger covers in a clean place . When changing lens, use adhesive paper to paste sealed window, prevent dust to enter the interior cause pollution



1、Pressing ring 2、Protective glass

Note : Remove in the direction of the arrow,
otherwise it may cause damages.

DO NOT operate with wrench or iron plier.





POWER



COOLING GAS



CUTTING GAS



Loosen the screws and remove




POWER



COOLING GAS





CUTTING GAS








1、Pressing ring 2、Protective glass

Note : Remove in the direction of the arrow, otherwise it may cause damages.

DO NOT operate with wrench or iron plier.



Note: To disassemble, use a special fixture to rotate and loosen the fixed gland. After taking out the lens, record the thickness and direction of the washer. After replacement, return to the original recording state in order.



Note: To disassemble, use a special fixture to rotate and loosen the fixed gland. After taking out the lens, record the thickness and direction of the washer. After replacement, return to the original recording state in order.



POWER




COOLING GAS



CUTTING GAS


Cutting head indicator light function



Monitor real-time status interface :



1. Monitoring value bar: real-time monitoring status of the cutting head.
2. Alarm value setting column: The default alarm value has been given (to change the alarm value, you need to click the "Alarm Threshold Setting" button and enter the authority password to confirm the change)



Alarm function description:

- When the monitored value exceeds the set alarm value, the system will alarm and continuously output an alarm signal (+24V voltage). It prompts that the current cutting head is abnormal, please consult after-sales personnel to troubleshoot the abnormality.
- After removing the abnormality, input the alarm reset signal (0V voltage) to cancel the cutting head alarm.



地 址 : 广东省深圳市龙华新区大浪街道浪口工业园青年梦工厂3栋3楼
Address : Floor 3, Building 3, Langkou Industrial Zone, Dalang,
Longhua District, Shenzhen

电话 T e l : +86 0755 27702280

传真 F a x : +86 0755 27702881

网址 W e b : www.szworthing.com.cn

邮箱 Email : szworthing@gmail.com