


PRODUCT INSTRUCTION MANUAL



GSL63 Wobble cutting head (FUJI servo)

Structure and function introduction



Shenzhen Worthing Technology Co Ltd

www.wsxlaser.com

Contents

| | |
|---|-----------|
| 1. Product structure | 1 |
| 1.1 Technical parameters | 1 |
| 1.2 Connections | 2 |
| 1.3 Installation size | 4 |
| 1.4 QBH fiber socket installation | 5 |
| 1.5 Coaxiality adjustment | 7 |
| 1.6 Kerf method to find zero focus and focus | 8 |
| 1.7 Replacement of Ceramic Ring & Nozzle | 9 |
| 1.8 Replacement of Lower Protection Window | 10 |
| 1.9 Replacement of Upper Protection Window | 11 |
| 1.10 Replacement of Focus Protection Window | 12 |
| 2. Electrical Specifications | 13 |
| 2.1 Electrical interface and definition | 13 |
| 2.2 Servo drive connection | 14 |
| 2.3 Power switch connection | 15 |
| 2.4 Limit signal connection | 16 |
| 2.5 Galvo connection | 16 |
| 2.6 USB to RS-485/422 converter connection | 16 |
| 3. Motor and limit switch inspection method | 17 |
| 4. Axis and WSX system connection | 18 |
| 5. WSX cutting system and pulse control line wiring instructions | 19 |
| 6. WSX cutting system platform configuration | 20 |
| 7. WSX cutting system platform configuration | 21 |
| 7.1 Procedure 1 | 21 |
| 7.2 Procedure 2 | 22 |
| 7.3 Procedure 3 | 23 |
| 7.4 Procedure 4 | 24 |
| 8. Monitoring function..... | 25 |
| 8.1 Installation of monitoring software..... | 25 |
| 8.2 Use of monitoring functions 1..... | 26 |
| 8.3 Use of monitoring functions 2..... | 27 |
| 9. Use of wobble functions..... | 28 |
| 10. Common fault alarm codes..... | 30 |

1. Product structure


1.1 Technical parameters


| Basic parameters | |
|----------------------------|--|
| Model: | GSL63 |
| Max working power | ≤6kw |
| Laser wavelength range | 1070±30nm |
| Fiber types | QBH, G5, QD |
| Collimation focal length | 100mm |
| Focusing focal length | 150mm/200mm |
| Focusing adjustment range | ±38mm (Focus length F200mm) |
| | ±21mm (Focus length F150mm) |
| Centering adjustment range | ±1.5mm |
| Cutting gas connection | φ 12mm (standard) or φ 10mm (optional); gas pressure ≤2.5Mpa |
| Cooling gas connection | φ 6mm; gas pressure ≤0.6Mpa |
| Cooling water connection | φ 6mm; gas pressure ≤0.6Mpa |
| Working temperature | 3℃ ~ 55℃ |
| Storage temperature | -20℃ ~ 55℃ |
| Weight | 12.7kg |

Note: To avoid damage during storage and transport:

1. The cutting head should be stored in the proper temperature and humidity;
2. Avoid vibration and shock;
3. Do not put the cutting head in or near magnetic fields (such as permanent magnets or strong alternating fields).


1.2 Connections





- 15. Nozzle
- 16. Ceramic ring
- 17. Moving signal
- 18. Cooling gas
- 19. Cooling water for Y axis wobble lens(in/out)
- 20. Focus dial
- 21. Cooling water for collimating lens(in/out)
- 22. Upper protective window
- 23. Cooling water for QBH

1.3 Installation size




1.4 QBH fiber socket installation

Note: · Fiber insertion and removal should be on a clean work bench;

· Before inserting the optical fiber, it is necessary to check whether the fiber end face and QBH interface are polluted;

· Horizontal insertion;


· After inserting the fiber, wrap white tape around the gap between the fiber and the cutting head interface.



1.Remove the protective film/cover from the fiber optic socket.


2.Insert the fiber optic plug (aligned) into the unlocked fiber optic socket (sealing cap in the lowest position) until it stops. The sealing cap closes and locks in the direction of the fiber (see Detail B). NOTE: Before inserting the plug, the dowel pin of the plug sealing cap must be aligned with the socket slot (see Detail A)

3. Pull the turning rim as the picture below



4.6. Turn the rim in the direction as picture below at moderate intensity to make it tight (Use thumb and index finger).


The red marks can be aligned to or over the middle of the white bar, but do not twist any more when it is in the right position.



Note: Do not twist vigorously , it may cause damage to precision machinery.

To avoid dust or dirt entering into the fiber optic connector by accident, please clean the fiber rod first. Insert the fiber plug with the laser head in a horizontal position.


1.5 Coaxiality adjustment




1. adjust the X/Y horizontal adjustment screws of with an Allen wrench so that the beam passes through the center of the nozzle.
2. when the beam passes through the center of the nozzle, the cutting effect is best.
3. If the beam does not pass through the center of the nozzle, it may cause no light and poor cutting effect.

Method for detecting whether the beam passes through the center of the nozzle:

1. using transparent tape on the nozzle (the nozzle should preferably be new or not deformed).
2. adjust the power of the laser to about 50W; (500W for example, adjust the spot power to 10 %)
3. after 1 to 2 seconds out of the light, remove the transparent tape.
4. the transparent tape facing the lighting source, observe the nozzle printed on the tape and the laser printed on the round burn spot through the tape is concentric.
5. if concentric, then the debugging results qualified; if not, then continue to debug until qualified.



X/Y adjusting



Concentric checking

1.6 Kerf method to find zero focus and focus

Purpose:

Correct the "rollback distance" to make the actual physical focus coincide with the software zero focus, and use it as a benchmark for subsequent process debugging.

Method:


1. Using the cutting kerf method, see the size of the cutting seam to determine the focus position. The kerf at the focus position is the smallest.
2. Correct the "rollback distance" to make the actual physical focus coincide with the software zero focus, and use it as the benchmark for subsequent process debugging.

For example: 1. Platform settings:


2. Start cutting from focus +6 displayed on the software, with an interval of 1mm, and cut to focus -2. It is observed that the fifth line is the thinnest, then the actual focus 0 is at the current software display focus +2 position.

3. Correction: If the actual focus of the kerf method is higher than the focus displayed by the software, then the rollback distance = rollback - difference value


Rollback distance=9-2=7, otherwise the same principle




1.7 Replacement of Ceramic Ring & Nozzle



1.8 Replacement of Lower Protection Window



Pay attention to dust: when removing and installing the lens, wear dust gloves and finger covers in a clean place . When changing lens, use adhesive paper to paste sealed window, prevent dust to enter the interior cause pollution.




1、Pressing ring 2、Protective glass


Note : Remove in the direction of the arrow, otherwise it may cause damages.

DO NOT operate with wrench or iron pliers.

1.9 Replacement of Upper Protection Window



Pay attention to dust: when removing and installing the lens, wear dust gloves and finger covers in a clean place . When changing lens, use adhesive paper to paste sealed window, prevent dust to enter the interior cause pollution.





1、Pressing ring 2、Protective glass

Note : Remove in the direction of the arrow with fixture tools, otherwise it may cause damages.

DO NOT operate with wrench or iron pliers.

1.10 Replacement of Focus Protection Window




1、Pressing ring 2、 Protective glass

Note : Remove in the direction of the arrow, otherwise it may cause damages.


DO NOT operate with wrench or iron pliers.

2. Electrical Specifications


2.1 Electrical interface and definition



Servo motor power interface




Servo motor encoder & approach switch interface



Monitoring signal interface

2.2 Servo drive connection




Note: 1. The driver input power is single-phase AC220V.

2. External braking resistor interface need not be connected.

3. Please refer to Fuji ALPHA5 series manual for drive commissioning.

2.3 Power switch connection



| No | |
|----|--|
| 1 | Fire Wire |
| 2 | Zero Wire |
| 3 | Ground |
| 4 | Output -15V |
| 5 | Output Negative |
| 6 | Output Negative |
| 7 | Output +15V |
| 8 | Output Voltage Adjustment (range: $\pm 10\%$) |

2.4 Limit signal connection

| No | | Description | Note |
|----|-----|----------------------------|------|
| 1 | 24V | Connect to power switch V+ | |
| 2 | 0V | Connect to power switch V- | |
| 3 | W+ | Connect to WSX system W+ | |
| 4 | W- | Connect to WSX system W- | |

2.5 Galvo connection

| No | | Description | Note |
|----|--------|--|------|
| 1 | 485A | Wiring with USB to RS-485/422 converter (T/R+) | |
| 2 | 485B | Wiring with USB to RS-485/422 converter (T/R-) | |
| 3 | +15V | Connect to power switch +15V | |
| 4 | -15V | Connect to power switch -15V | |
| 5 | GND | Connect to power switch COM | |
| 6 | GSTA1 | Alarm output signal (alarm output 24V) | |
| 7 | GSAT2 | | |
| 8 | ON/OFF | Reserved | |
| 9 | IN/COM | Reserved | |
| 10 | GALA1 | Reserved | |
| 11 | GALA2 | Reserved | |
| 12 | PE | Connect to ground PE | |

2.6 USB to RS-485/422 converter connection

| No | | Description | Note |
|----|------|-----------------|------------------------------|
| 1 | T/R+ | Connect to 485A | Connect USB port to computer |
| 2 | T/R- | Connect to 485B | |
| 3 | RXD+ | - | |
| 4 | RXD- | - | |
| 5 | GND | - | |

3 Motor and limit switch inspection method:


Motor inspection process:

1. Instrument: Multimeter.
2. Set the multimeter to 200 Ω resistance or buzzer on/off.
3. Measure the motor U, V, W, it is recommended to take in the cutting head aviation plug end.
4. motor U/V, U/W, V/W each two-phase resistance of about 17-20 Ω , on and off gear beeping sound for the motor is normal. If the resistance is 0 Ω , or infinity is abnormal for the motor.
5. Motor U, V, W any phase are not conductive with PE or shell, if there is then the motor is abnormal.

Limit switch inspection process:

1. Instrument: multimeter, adjusted to DC gear.
2. No special requirements, limit switch is NPN type normally closed signal.
3. It is recommended to measure when the focus is at 0 position.
4. Tap the servo motor to confirm whether the motor can be forward and reverse.
4. Connect 24V and 0v to the DC24V power supply, and do not connect W+ and W1.
5. Multimeter red pen to measure 24V, black pen to measure the W + or W -. The focus in the 0 position output voltage of 24V, focus In the positive limit or negative limit output voltage is 0v.

4 Axis and WSX system connection:




24V input

Note:

1. Pulse control line connects to the W axis of the system.
2. System W +, W- connects to focus axis limit switch W +, W- signal.



5 WSX cutting system and pulse control line wiring instructions



Fuji servo pulse parameters

| parameter | value | parameter | value | parameter | value |
|-----------|-------|-----------|-------|-----------|-------|
| PA1-01 | 0 | PA1-05 | 10000 | PA1-27 | 50 |
| PA1-03 | 30 | PA1-08 | 2500 | PA1-28 | 50 |
| PA1-04 | 1 | PA1-15 | 28 | | |

6 WSX cutting system platform configuration



Operation Procedure: Click platform configuration tool > Password (27702881) > OK > Enter system parameter configuration > Focus control

7 Greenlink RS485 driver installation process

7.1 Procedure 1




Procedure: Click computer properties > System type > Version > Install the serial port driver, select the file corresponding to the computer to install.

7.2 Procedure 2

| 名称 | 修改日期 | 类型 | 大小 |
|--------------------------|-----------------|-----|----|
| Android (Java D2XX) | 2022/10/20 9:12 | 文件夹 | |
| CDMUninstaller_v1.4-卸载工具 | 2022/10/20 9:13 | 文件夹 | |
| Linux | 2022/10/20 9:15 | 文件夹 | |
| Windows | 2022/10/20 9:15 | 文件夹 | |

| | | | |
|------------------------------------|-----------------|-----|--|
| Windows 7 | 2022/10/20 9:15 | 文件夹 | |
| Windows 8 10 11、Server 08R2 2012R2 | 2022/10/20 9:15 | 文件夹 | |
| Windows CE | 2022/10/20 9:15 | 文件夹 | |
| Windows RT | 2022/10/20 9:15 | 文件夹 | |
| Windows XP | 2022/10/20 9:15 | 文件夹 | |



Procedure: Open the serial line FT231XS chip driver file > Windows > Windows 8 10 11 > CDM212364_Setup > Extract

7.3 Procedure 3



Operation Procedure: Click the next page> I accept this agreement> Next page

7.4 Procedure 4



Procedure: Click to complete

Note:

1. Click Computer Properties › Device Manager › to see if the port is marked with an exclamation mark, no exclamation mark indicates that the installation was successful.
2. The driver installation package can be downloaded from the Greenlink's official website.

8 Monitoring function

8.1 Installation of monitoring software

名称

修改日期

类型

大小

GSL63 (温控版V4.0.0 波特率9600)

2023/4/21 10:49

文件夹

GSL63

2023/4/21 10:48

应用程序

GSL63

Channel: COM1

Connect

Monitor

Galvano...

| Sensor | Real time value | Warning value | Alarm value | Operation |
|-----------------------------------|-----------------|---------------|-------------|---------------|
| Collimating mirror | 0.0℃ | 0.0 | 0.0 | Set threshold |
| Focus mirror | 0.0℃ | 0.0 | 0.0 | Set threshold |
| Focus protective mirror | 0.0℃ | 0.0 | 0.0 | Set threshold |
| Drawer protection mirror | 0.0℃ | 0.0 | 0.0 | Set threshold |
| Focus cavity pressure | 0.00Bar | 0.0 | 0.0 | Set threshold |
| Protective mirror cavity pressure | 0.00Bar | 0.0 | 0.0 | Set threshold |

Galvfirmware: 00000

Monitorfirmware: 00000


Software: V4.1.2

Operation procedure: Open the GSL (temperature control version V4.0.0 baud rate 9600) file package> Click GSL63 > open the monitoring page

8.2 Use of monitoring functions 1




Operation Procedure: Select the corresponding serial port › Connect › Monitor



Operation Procedure: Set threshold › Enter password (666666) › Confirm

8.3 Use of monitoring functions 2



Operation Procedure: Modify temperature parameters › OK

9 Use of wobble functions



Operation Procedure: Select the corresponding serial port › Connect ›

Galvanometer



Operation procedure: Modify the parameter password (666666) ›

Confirm › Click the galvanometer switch

10 Common fault alarm codes

| Alarm codes | | Alarm codes | |
|-------------|---|-------------|--|
| oc1 | Overcurrent 1 | LuP | Insufficient voltage in main circuit |
| oc2 | Overcurrent 2 | rH1 | Internal regenerative resistor overheating |
| oS | Overspeeding | rH2 | External regenerative resistor overheating |
| Hu | Overvoltage | rH3 | Regenerative transistor abnormal |
| Et1 | Encoder abnormal 1 | oF | Out of tolerance |
| Et2 | Encoder abnormal 2 | AH | Amplifier overheat |
| ct | Control circuit abnormal | EH | Encoder overheat |
| dE | Memory abnormal | dL1 | Loss of ABS data1 |
| Fb | Fuse broken | dL2 | Loss of ABS data2 |
| cE | Motor combination abnormal | dL3 | Loss of ABS data3 |
| tH | Regenerative transistor overheating | AF | Multi-rotation overflow |
| Ec | Encoder communication abnormal | E | Initialization error |
| ctE | CONT repeat | PoF | Servo motor not energized |
| oL1 | Overload 1 | Pn0 | Zero speed stop |
| oL2 | Overload 2 | PP1 | Pulse train input operation |
| rH4 | Inrush suppression current circuit abnormal | Pot | Detection of overtravel signals in positive/negative direction |



Shenzhen Worthing Technology Co., Ltd.

Tel: +86 755 27702280

Web: www.wsxlaser.com

Email: info@wsxlaser.com

Add: Building3, Langkou Industrial Zone, Dalang, Longhua District,
Shenzhen, Guangdong, PRC