




Automatic Focusing Fiber
Laser Cutting Head
NC12



User Manual

Shenzhen Worthing Technology Co.,Ltd.

Attention

Please read this manual carefully and make sure you understand its contents before using the laser head.

Please keep this manual for future operation and maintenance.

Test Condition

Correct wiring, normal electric, good earthing with smoothing and voltage stabilizing circuit.




Steps


1. Adjust soft limitation to -100~100
2. Set inching speed to 1mm/s
3. Inching at positive direction until reach positive limitation
4. Inching at negative direction until reach negative limitation
5. After confirming effectiveness of positive & negative limitation, set back to origin
6. Restore soft limitation & inching speed to origin


Instruction



1. Make sure manual inching can find limit switch
2. Reduce manual speed to ensure that invalid limitation will not cause structural damage.
3. Make sure wire connection of negative limitation switch is correct and signal is normal
4. It's allowed to restore to origin automatically only after confirming positive & negative limitation
5. Restore parameters to ensure system running correctly



1. QBH Fiber Access
2. Cooling Water Connector
3. X/Y Horizontally Adjusting Screw
4. Installation Plate
5. Height Adjustment Installation Position
6. Focusing Scale Window
7. Protective Window Component
8. Gas Pipe Connector
9. Height Adjustment Singal Interface
10. Sensor
11. Ceramic Ring
12. Nozzle








10P Aviation Plug	
Pin	Signal
1	Null
2	A+(Stepper Motor A Phase Power Line)
3	A-(Stepper Motor A Phase Power Line)
4	B+(Stepper Motor B Phase Power Line)
5	B-(Stepper Motor B Phase Power Line)
6	+24V(Approach Switch Power Line)
7	0V(Approach Switch Power Line)
8	W+(Approach Switch Signal Line)
9	W-(Approach Switch Signal Line)
10	Null

Motor Power Supply & Approach Switch Interface (Green)

Friendless FSCUT2000A laser cutting control system BCL3764 terminal W axis DB15 servo control interface connect with Sansha driver interface definition




Note:

- 1.Definitions of servo driver and servo motor connector shown in Sansha MD-2422 driver instruction;
- 2.Please use independent DC power: DC24V 6A, Vdc+ connects to+24V , GND connects to 0V.
- 3.Lines inside red dotted box can be not connected, default dangling is enabling

Friendless D15 servo control interface		Sansha stepping driver	
Signal	Pin		Signal
PUL+	1		PUL+ (CW+)
PUL-	9		PUL- (CW-)
DIR+	2		DIR+ (CW+)
DIR-	10		DIR- (CW-)
A+	3		Null
A-	11		Null
B+	4		Null
B-	12		Null
Z+	5		Null
Z-	13		Null
24V	8		Null
SON	6		Null
CLK	7		Null
ALM	14		Null
0V	15		GND

Definition of laser focusing djustment range limitation switch connector




Stepping subdivision and current setting

Stepping Driving Setting

SW1	OFF	1.4A
SW2	OFF	
SW3	ON	
SW4	OFF	
SW5	OFF	10000
SW6	ON	
SW7	OFF	
SW8	OFF	

parameters are subject to the table, the picture is for examlle only




Note:


- 1.Current can not be higher than 1.4A, otherwise will cause burned damage to equipment;
- 2.Parameters are subject to the table, the picture is for examlle only

1. Place the laser head and optical fiber connector in a horizontal state;
2. Clean the QBH and fiber connector with clean rod and ethyl alcohol.


Inside the red circle is the plug of fiber rod; it is equipped with a protective cover. Before installation, tighten the cover to avoid it being loose during the processing which may cause offset light path and bad cutting quality or even cause burn damage to the fiber rod and cutting head.




3. Insert the fiber connector into QBH gently;



4. After inserting, turn the turning rim in the arrow direction until the two red marks are aligned to the white mark




5. Then pull the turning rim as the picture below;



6. Turn the rim in the direction as picture below at moderate intensity to make it tight (Use thumb and index finger).


The red marks can be aligned to or over the middle of the white bar, but do not twist any more when it is in the right position.



Note: Do not twist vigorously , it may cause damage to precision machinery.




To avoid dust or dirt entering into the fiber optic connector by accident, please clean the fiber rod first. Insert the fiber plug with the laser head in a horizontal position.



1. Y-Direction Horizontally Adjusting Screw
2. X-Direction Horizontally Adjusting Screw

1. Adjust the X/Y screw by allen wrench and make the beam pass through the center of nozzle;
2. The cutting effect is best when the beam pass through the center of nozzle;
3. If the beam does not pass through the center of nozzle, it may cause the beam could not be emitted out or bad cutting effect and so on.



Methods of testing whether the beam pass through the center of nozzle:

1. Paste the transparent tape on the outlet of the nozzle (prefer to a new or undeformed nozzle);
2. Set the power of laser machine to 50W (take 500W for example, adjust the short burst power for 10%);
3. Take off the transparent tape after the beam has been emitted for 1 - 2 seconds;
4. Face the tape to light source and observe the round mark of nozzle on the tape and burning spot of laser passing through the tape.
5. If they are concentric, the testing result is good, but if not, please keep adjusting.
6. When adjustment is finished, tighten the center locking ring (red part) immediately.

beam passes through the center (correct)

beam does not pass through the center (incorrect)

Focus Control

☒ Enable

☒ The fourth axis ☐ Precitec ☐ HighYAG ☐ BCL4516E[No Connection]

 Focus Range: From to

 Focus position at org:

 Pulse Rate: Move need pulse

 High Speed: Org Dir ☒ Pos ☐ Neg

 Low Speed: ORG signal:

 Rollback distance:

 Jog speed:

 Locate Speed:

 acceleration:

 Servo Alarm Logic

 Negative Limit Logic:

 Positive Limit Logic:

Note: 1.This parameter is default value; when user changes it, please avoid hard ware damage;

2. Please contact technician to get specific parameters of different lens combinations.

Return Org

☐ Soft limit

☐ Prompt go Org at start

☐ Prompt go Org in warning

 X ORG direction: ☒ Neg ☐ Pos

 Y ORG direction: ☒ Neg ☐ Pos

 ORG signal: ☒ Org ☐ Limit

 Limit logic:

 Z-Phase signal: ☒ Enable

 High Speed:



 X rollback dis:

 Low Speed:


 Y rollback dis:

Name	Logic	
X +limit	<input checked="" type="radio"/> NO	<input type="radio"/> NC
X -limit	<input checked="" type="radio"/> NO	<input type="radio"/> NC
X origin	<input checked="" type="radio"/> NO	<input type="radio"/> NC
Y +limit	<input checked="" type="radio"/> NO	<input type="radio"/> NC
Y -limit	<input checked="" type="radio"/> NO	<input type="radio"/> NC
Y origin	<input checked="" type="radio"/> NO	<input type="radio"/> NC
W +limit	<input type="radio"/> NO	<input checked="" type="radio"/> NC
W -limit	<input type="radio"/> NO	<input checked="" type="radio"/> NC
W origin	<input type="radio"/> NO	<input checked="" type="radio"/> NC


Note: 1.Please choose normally closed mode for normally closed limitation switch.




Step 1: set the laser power to 500W, make a short burst at the height of 5cm from the plate, burn a round scorch on the plate;



Step 2: set the laser power to 100W, make a short burst at the height of 1~5 cm from the plate, burn a round scorched spot on the plate;



Step 3: compare the concentricity;





Check



Distance



Replace



Adjust the lens



Maintenance



Maintenance
Period




Calibration


Note:

Before maintenance, clean away the dust on the surface of the head with compressed air; then use clean cloth and ethyl alcohol to clean the related parts.

Note:

When the maintenance of ceramic ring & nozzle is finished, it is necessary to calibrate every time.






POWER



COOLING GAS




CUTTING GAS




Note:

Before maintenance, clean away the dust on the surface of the head with compressed air; then use clean cloth and ethyl alcohol to clean the related parts.




Note:

When the maintenance of ceramic ring & nozzle is finished, it is necessary to calibrate and test the beam to see whether it is in the center.




center checking



Pay attention to dustproof

Before maintenance, record the position and orientation of the lens; After maintenance, assemble as the record




1 Slide Gasket 2 Pedestal 3 Protective Window 4 Seal Ring

Note: Parts 3~4 must be removed in the direction of the arrow, otherwise it may cause damages.

It's not necessary to take out Slide Gasket every time, but remember to check it. DO NOT operate with wrench or iron plier.





Note:

Before maintenance, clean away the dust on the surface of the head with compressed air; then use clean cloth and ethyl alcohol to clean the related parts.



POWER




COOLING GAS




CUTTING GAS




Before maintenance,
record the position and
orientation of the lens;
After maintenance,
assemble as the record





Beware of
Dropping



1 Gland 2 Protective Window 3 O-Type Ring Outer30*1.0



Note:
Before maintenance, clean away the dust on the surface of the head with compressed air; then use clean cloth and ethyl alcohol to clean the related parts.



POWER



COOLING GAS



CUTTING GAS

1. Before maintenance, record the position and orientation of the lens; After maintenance, assemble as the record
2. Twist to the end and then turn backward 1/5 circle to prevent the lens being affected by temperature variation.

Note:

Before maintenance, clean away the dust on the surface of the head with compressed air; then use clean cloth and ethyl alcohol to clean the related parts.




POWER





COOLING GAS



CUTTING GAS



1. Before maintenance, record the position and orientation of the lens; After maintenance, assemble as the record
2. Twist to the end and then turn backward 1/5 circle to prevent the lens being affected by temperature variation.





地 址：广东省深圳市龙华新区大浪街道浪口工业园青年梦工厂3栋3楼
Address : Floor 3, Building 3, Langkou Industrial Zone, Dalang,
Longhua District, Shenzhen

电话 T e l : +86 0755 27702280

传真 F a x : +86 0755 27702881

网址 W e b : www.szworthing.com.cn

邮箱 Email : info@szworthing.com.cn